










cservice@allanson.com | 1.800.661.7251 | www.allanson.com Information in this manual is subject to change without prior notice



Project Planning and Preparation(s)

What you will need for parts and pieces...



Step One: Take a linear measurement of the overall length of the portion of the building where you plan to install the border tube(s).


Step Two: Divide the overall length by the best stock sized tube(s) to achieve the most esthetically appealing installation. For example if this building was 37' long the optimal sized tube would be ARBT-74-RGB meaning that the tube is 74" long and White when not lit. Based on that you would specify (6) of this unit P/N to complete the project with the least amount of seams.








Project Planning Laying Out the Installation:



Step Three: Using a Level or a Chalk line make a line across the entire length of the installation This will ensure that each tube applied will stay on the same level plane.

Step Four: After you have determined how may mounting clips you will need, install them spaced according to the length of the specified tube(s), spacing them + or - 24.5" on center. for pieces less than 26" long you will install the fixture using one spring clip on each end.




cservice@allanson.com | 1.800.661.7251 | www.allanson.com







Project Installation and Wiring:

Note: All electrical connections must be completed by qualified person(s) and in accordance to local electrical codes.








Step Five: Install the border tubes beginning at an end while making sure not to compress the soft end caps leaving a minimum of 1/4" between each fixture, thus allowing for normal expansion and contraction.

Step Six: Make all electrical connections based on the manufacturers' recommendations and test lighting. Finish all connections and apply primary power and verify all tubes are lighting.












Page 4/9



Installation and Mounting Hardware Spring Clip

- - Based on the different installation conditions the fastener will be determined and provided by the installer.




The position of the Stainless Steel Snap and Aluminum Slide clips are vital to a successful installation both from a mechanical and esthetic view. There should not be any section of the installation that measures longer than 25" without an Aluminum Slide clip in place as directed.








Installation and Mounting Hardware In-line Brackets






Aluminum Slide Clip

Will need to be placed in-line on or about 25" on center along with one Snap cip on each end.

See illustration at left: When marking off and laying out your Slide Brackets pay close attention to the angle of the surface making sure that they are same across the length of the project. Failing to do so can cause the Slide Clips to apply uneven pressure in the mounting flange possibly leading to cracking of the housing and eventual failure of the border tube.

The best way to determine where to apply the clips is to use a long level straight edge across the face of the building and mark the points where all Clips wil be on the same level plane.

Note: there may be times where you may have to shim some of the Clips along the way to maintain the same plane.



Note: As little as five degrees off will alter the tube enough to noticeably distort the overall line.







PART#ClipClipClipARBT-04211ARBT-07211	
ARBT-07 2 1 1	
ARBT-09 2 1 1	
ARBT-11 2 1 1	
ARBT-14 2 1 1	
ARBT-16 2 1 1	
ARBT-19 2 1 1	
ARBT-21 2 1 1	
ARBT-23 3 1 1	
ARBT-26 3 1 1	
ARBT-28 3 1 1	
ARBT-31 3 1 1	
ARBT-33 3 1 1	
ARBT-35 3 1 1	
ARBT-38 3 1 1	
ARBT-40 3 1 1	
ARBT-43 3 1 1	
Mounting HardwareARBT-45311ARBT-45311	
ARBT-47 3 1 1	
ARBT-50 3 1 1	
ARBT-52 4 1 1	
ARBT-55 4 1 1	
ARBT-57 4 1 1	
ARBT-59 4 1 1	
ARBT-62 4 1 1	
ARBT-64 4 1 1	
ARBT-67 4 1 1	
ARBT-69 4 1 1	
ARBT-71 4 1 1	
ARBT-74 4 1 1	
ARBT-76 4 1 1	
ARBT-79 5 1 1	
ARBT-81 5 1 1	
ARBT-83 5 1 1	
ARBT-86 5 1 1	
ARBT-88 5 1 1	
ARBT-91 5 1 1	
ARBT-93 5 1 1	
ARBT-95 5 1 1	
ARBT-98 5 1 1	Pag



cservice@allanson.com | 1.800.661.7251 | www.allanson.com






General Wiring Diagram (24V)

For custom wiring diagrams, please contact your local Allanson Sales Representative

ACL-WIFI-103 with ACL-3063-3A & ARBT-XXRGB



Tried • Trusted • True cservice@allanson.com | 1.800.661.7251 | www.allanson.com





Installation and service of these products should be done by qualified personnel. Use only with Class 2 Power Supply.



To reduce the risk of electric shock, disconnect all connections before servicing.



Page 9/9





ARBT - Static Colors SkyLine LED Rigid Border Tube Installation Instruction






cservice@allanson.com | 1.800.661.7251 | www.allanson.com Information in this manual is subject to change without prior notice



Project Planning and Preparation(s)

What you will need for parts and pieces...



Step One: Take a linear measurement of the overall length of the portion of the building where you plan to install the border tube(s).


Step Two: Divide the overall length by the best stock sized tube(s) to achieve the most esthetically appealing installation. For example if this building was 41' long the optimal sized tube would be ARBT-98-CW meaning that the tube is 98" long and Cool White in color. Based on that you would specify (5) of this unit P/N to complete the project with the least amount of seams.








Project Planning Laying Out the Installation:



Step Three: Using a Level or a Chalk line make a line across the entire length of the installation This will ensure that each tube applied will stay on the same level plane.

Step Four: After you have determined how may mounting clips you will need, install them spaced according to the length of the specified tube(s), spacing them + or - 24.5" on center. for pieces less than 26" long you will install the fixture using one spring clip on each end.



Tried • Trusted • True cservice@allanson.com | 1.800.661.7251 | www.allanson.com Page 2/9


#**21-**07.2/







Project Installation and Wiring:

Note: All electrical connections must be completed by qualified person(s) and in accordance to local electrical codes.








Step Five: Install the border tubes beginning at an end while making sure not to compress the soft end caps leaving a minimum of 1/4" between each fixture, thus allowing for normal expansion and contraction.

Step Six: Make all electrical connections based on the manufacturers' recommendations and test lighting. Finish all connections and apply primary power and verify all tubes are lighting.









Do not cut this product without using the Field Cut Kit and without referencing the Field Cut Kit Instructions.

Do Not Drill through the mounting flange or any part of the fixture for any reason it will Void Warranty

Allanson

Tried • Trusted • True cservice@allanson.com | 1.800.661.7251 | www.allanson.com



Handle with care, Do Not Force, striking this product will Void Warranty








Installation and Mounting Hardware Spring Clip

- - Based on the different installation conditions the fastener will be determined and provided by the installer.




The position of the Stainless Steel Snap and Aluminum Slide clips are vital to a successful installation both from a mechanical and esthetic view. There should not be any section of the installation that measures longer than 25" without an Aluminum Slide clip in place as directed.








Installation and Mounting Hardware In-line Brackets






Aluminum Slide Clip

Will need to be placed in-line on or about 25" on center along with one Snap cip on each end.

See illustration at left: When marking off and laying out your Slide Brackets pay close attention to the angle of the surface making sure that they are same across the length of the project. Failing to do so can cause the Slide Clips to apply uneven pressure in the mounting flange possibly leading to cracking of the housing and eventual failure of the border tube.

The best way to determine where to apply the clips is to use a long level straight edge across the face of the building and mark the points where all Clips wil be on the same level plane.

Note: there may be times where you may have to shim some of the Clips along the way to maintain the same plane.



Note: As little as five degrees off will alter the tube enough to noticeably distort the overall line.







	PART #	Stainless Steel Snap Clip	Aluminum Slide Clip	Wire Retainer Clip	
	ARBT-04	2	1	1	
	ARBT-07	2	1	1	
	ARBT-09	2	1	1	
	ARBT-11	2	1	1	
	ARBT-14	2	1	1	
	ARBT-16	2	1	1	
	ARBT-19	2	1	1	
	ARBT-21	2	1	1	
	ARBT-23	3	1	1	
	ARBT-26	3	1	1	
	ARBT-28	3	1	1	
	ARBT-31	3	1	1	
	ARBT-33	3	1	1	
	ARBT-35	3	1	1	
	ARBT-38	3	1	1	
	ARBT-40	3	1	1	
	ARBT-43	3	1	1	
Mounting Hardware	ARBT-45	3	1	1	
	ARBT-47	3	1	1	
	ARBT-50	3	1	1	
	ARBT-52	4	1	1	
	ARBT-55	4	1	1	
	ARBT-57	4	1	1	
	ARBT-59	4	1	1	
	ARBT-62	4	1	1	
	ARBT-64	4	1	1	
	ARBT-67	4	1	1	
	ARBT-69	4	1	1	
	ARBT-71	4	1	1	
	ARBT-74	4	1	1	
	ARBT-76	4	1	1	
	ARBT-79	5	1	1	
	ARBT-81	5	1	1	
	ARBT-83	5	1	1	
	ARBT-86	5	1	1	
	ARBT-88	5	1	1	
	ARBT-91	5	1	1	
	ARBT-93	5	1	1	
	ARBT-95	5	1	1	
	ARBT-98	5	1	1	_
					Page




cservice@allanson.com | 1.800.661.7251 | www.allanson.com





Installation and Secondary Fixture Wiring



Page 8/9

cservice@allanson.com | 1.800.661.7251 | www.allanson.com





Product Code	be Length Code	COOL WHITE	RED	BLUE	GREEN	ORANGE	XELLOW	Fixture Length	Fixture Length
Ъ Ц	Tube	CW	RD	BL	GR	OR	YL	<u> </u>	<u> </u>
	⊢	Watts	Watts	Watts	Watts	Watts	Watts	millimeters	Inches
ARBT-	14	2.04	2.04	2.04	2.04	2.04	2.04	349mm	13.75"
ARBT-	26	4.08	4.08	4.08	4.08	4.08	4.08	654mm	25.75"
ARBT-	50	8.18	8.18	8.18	8.18	8.18	8.18	1264mm	49.75"
ARBT-	74	12.24	12.24	12.24	12.24	12.24	12.24	1873mm	73.75"
ARBT-	98	18.64	18.56	19.04	18.72	18.72	19.04	2494mm	98.20"

Installation and service of these products should be done by qualified personnel. Use only with Class 2 Power Supply.



To reduce the risk of electric shock, disconnect all connections before servicing.

